

SIZE CHART - KIDS FUN

SHOE SIZE	CALF / HEIGHT (CM)			
	NORMAL		SLIM-TALL	
	WIDTH	HEIGHT	WIDTH	HEIGHT
29	23,5	29,5		
30	24,5	30,5		
31	25,5	31		
32	26,5	32		
33	27,5	33		
34	28,5	34,5		
35	29,5	36	28	39
36	30,5	37,5	29	41
37	31,5	39	30	44
38	32	41	31	46
39	33	43	32	47
40			33	48
41			34	49